



1-CP



BL JP

GND ZHW 0059200 MHZ GND

+5V


Reset

SCK

MosI

Miso

J1



RANGMANG

ATMEGA128



+5v

GND

TX

RX



GND



+POWER

